

Lesson 4 Action Group Download

1. Preface

The robotic arm is like a human arm. They both need “muscle memory” to perform their motor functions. Therefore, action group must be downloaded into the control board to execute actions.


2. Download Method

- 1) Turn on the robotic arm, and then connect it to the computer and open Python editor.




- 2) Click to connect device. (If fail to connect, please refer to “5.Appendix - > FAQ”)


- 3) After connecting, right click “workspace”, and select “change workspace”. Then find the action group file “xArm-ESP32 rob” in “5.Appendix”.



- 4) The file will be automatically added to the local project after selecting.



- 5) Select all the action files (from “00.rob to “60.rob””)



- 6) After downloading, “Download ok!” are be prompted in lower right corner.



- 7) After downloading, click “device” to check the files. If the file order is chaos, you can click “File-> Refresh Files”.

Note: If there is a single failure in a batch download, you can right click that file to download again.

